

RELIABLE DATA FIRST TIME EVERY TIME

OVERVIEW

The EX1200-4128 is an ultra high-density matrix module that allows the user to connect any input row to any output column with an SPST relay at every row/column crosspoint. This architecture provides the framework for flexible switch system designs where multiple test instruments need to be connected to common test points. The one-wire architecture allows for any of the 128 row inputs to be connected to any of the 4 column outputs.

The four output columns can be routed to the EX1200 series internal analog backplane to build large matrices or to connect to the optional 6.5 digit DMM, which also limits the amount of external cabling required. A (4×512) 1-wire matrix can be accommodated in only four slots of an EX1200 series mainframe, as an example.

Stub-breaking relays can remove a matrix module from the backplane to increase signal integrity of measurements being made on other modules. All relays are failsafe which ensures that no undesired signals are present at the user interface in the case of power interruption.

BLOCK DIAGRAM



RELIABLE DATA FIRST TIME EVERY TIME

EX1200-4128 128 x 4 Single-Pole Matrix

General Specifications

| CHANNEL COUNT | | | |
|--|--|--|--|
| MAXIMUM SWITCHING VOLTAGE | | | |
| MAXIMUM SWITCHING CURRENT | | | |
| MAXIMUM SWITCHING POWER ¹ | | | |
| MINIMUM CONTACT RATING | | | |
| RATED SWITCH OPERATIONS | | | |
| Mechanical | | | |
| Electrical | | | |
| SWITCHING TIME | | | |
| PATH RESISTANCE | | | |
| INSULATION RESISTANCE | | | |
| MAXIMUM THERMAL OFFSET PER CHANNEL (HI-LO) | | | |
| BANDWIDTH (-3 dB) | | | |
| CROSSTALK (TYPICAL) | | | |
| 1 MHz | | | |
| 10 MHz | | | |
| ISOLATION (TYPICAL) | | | |
| 1 MHz | | | |
| 10 MHz | | | |
| CONNECTOR TYPE | | | |

4 x 128 one-wire cross-point matrix 250 V AC, 220 V DC 1 A 60 W, 62.5 VAv 100 µV 1 x 10⁸ 1 x 10⁵ at full load 5 ms typical < 1 Ω $> 1 \text{ X} 10^9 \Omega$ $< 10 \ \mu V$ 3 MHz (typical) < -55 dB < -30 dB < -60 dB < -30 dB 160-pin

Notes:

1. Maximum switched power is derated non-linearly as voltage is increased.

Ordering Information

| EX1200-4128 | 128 x 4 single-pole matrix | | |
|-----------------------|---|--|--|
| ACCESSORIES AND TOOLS | | | |
| 70-0363-504 | Strain relief bracket (includes connector, recommended accessory) | | |
| 70-0363-503 | Strain relief bracket kit (without connector) | | |
| 52-0109-000 | Crimp pin (includes 100 crimp pins) | | |
| 27-0088-160 | Mating connector (one per board) | | |
| 46-0010-000 | Crimp tool (DIN) | | |
| 46-0011-000 | Extraction tool (DIN) | | |
| 70-0363-505 | 160-pin, unterminated cable assembly, 3 ft | | |
| 70-0367-005 | EX1200-TB160SE terminal block, single-ended module | | |
| | | | |

RELIABLE DATA FIRST TIME EVERY TIME